

CE



920P

**Humidity & Temperature Meter**

Humidity Measuring	
<b>Functions</b>	°C / °F / RH Selection, MAX / MIN, Auto Power Off
<b>Range</b>	0% ~ 100% RH
<b>Accuracy</b>	± 3%RH (25°C , 20 ~ 80% RH) ± 3.5%RH (At Other Ranges)
<b>Resolution</b>	0.01%RH
Temperature Measuring	
<b>Range</b>	- 20°C ~ 80°C / - 4°F ~ 176°F
<b>Accuracy</b>	±0.5°C / ±0.9°F (25°C) ±0.8°C / ±1.5°F (At Other Ranges)
<b>Resolution</b>	0.01°C / 0.01°F
<b>Power</b>	9V Battery
<b>Dimension</b>	173 x 56 x 39mm (approx.)
<b>Weight</b>	139gms Including Battery (approx.)
<b>Accessories</b>	Carrying Case, Inst. Manual, 9V Battery (installed)



961P

**Air Flow Anemometer**

Air Flow Measuring	
<b>Functions</b>	m / Sec, Ft / min, Knots, Km / h, MPH, CFM, MAX / MIN / HOLD, Auto Power Off
<b>Range</b>	1 ~ 25m/s
<b>Accuracy</b>	± (3% rdg ± 0.2m/s)
<b>Resolution</b>	0.01m/s
Temperature Measuring	
<b>Range</b>	0 ~ 50°C, 32 ~ 122°F
<b>Accuracy</b>	± 2°C / ± 4.0°F
<b>Resolution</b>	0.1°C / 0.1°F
<b>Power</b>	9V Battery
<b>Dimension</b>	202 x 56 x 39mm (approx.)
<b>Weight</b>	155gms Including Battery (approx.)
<b>Accessories</b>	Carrying Case, Inst. Manual, 9V Battery (installed)



**Digital Sound Level Meter**

970P



**Digital LUX Meter**

930P



**Digital LUX Meter with Flexible Sensor**

930T

<b>Functions</b>	MAX / MIN / HOLD, Auto Power Off	MAX / MIN, Backlight, Auto Power Off	MAX / MIN, Backlight, Auto Power Off with Disable Feature, Data Hold
<b>Range</b>	35dB ~ 130dB (31.5Hz ~ 8 KHz)	0 ~ 200,000 lux 0 ~ 20,000 fc	0.1 ~ 200,000 lux 0.0 ~ 20,000 fc
<b>Accuracy</b>	± 1.5dB (under reference conditions)	±5% rdg+10 dgt (<10,000 lux/fc) ±10% rdg+10 dgt (>10,000 lux/fc)	±3% + 30 dgt
<b>Resolution</b>	0.1dB	0.1lux or 0.1fc	0.1 lux or 0.1 fc
<b>Selection</b>	-	lux / fc	lux / fc
<b>Power</b>	9V Battery	9V Battery	1.5V AAA x 2 Batteries
<b>Dimension</b>	172 x 56 x 39 mm (approx.)	190 x 56 x 39mm (approx.)	157 x 54 x 34mm (approx.)
<b>Weight</b>	144gms Including Battery (approx.)	135gms Including Battery (approx.)	70gms Including Battery (approx.)
<b>Accessories</b>	Carrying Case, Inst. Manual, 9V Battery (installed)	Carrying Case, Inst. Manual, 9V Battery (installed)	Carrying Case, Inst. Manual, 1.5V AAA x 2 Batteries (installed)